

WIPES FOR LENS CLEANING

Specially Designed for Cleaning
High Power CO₂ Laser Lenses

Ophir Optics **EZ Clean™** and **EZ Clean™ Plus** are innovative disposable wipes for routine cleaning and deeper cleaning of optical High Power Laser Lenses. Composed of special non-scratch fabric, the liquid dipped wipes deposit a pre-measured amount of quick-drying cleaning fluid that leaves no residue.

EZ Clean

Composed of special non-scratch fabric, EZ Clean Wipes deposit a pre-measured amount of ethanol, which is ideal for routine cleaning of laser lenses.

A single wipe cleans one lens in a matter of seconds, replacing a five-step procedure using ethanol, cotton swabs and lens paper.



EZ Clean ^{Plus}

ECO-FRIENDLY VINEGAR WIPES
FOR LENS CLEANING

EZ Clean™ Plus, Ophir's most recent innovative wipe, is used for deeper cleaning of optical laser lenses in conjunction with Ethanol based EZ Clean™ Wipes (see above).

When deeper cleaning is required, EZ Clean™ Plus wipes are used to counteract the quick-drying effect of the ethanol with a vinegar-based solution that separates dust and other contaminants from the lens surface more effectively.

A final once-over with a new Ethanol based wipe removes any residue, and in a matter of seconds the lens is clean and ready for use.



Ophir EZ-Clean™ and EZ Clean™ Plus Packages each include 24 ready-to-use wipes; A few seconds cleaning translates into longer lens life-time and significantly shorter down-time for our customers' lasers.

LENS CLEANING INSTRUCTIONS

Routine Lens Cleaning Instructions Using

EZ Clean™ Wipes



Step 1:

Separate one EZ Clean™ wipe



Step 2:

Take out the folded EZ Clean™ wipe



Step 3:

Using an "S" motion, wipe from top to bottom



Step 4:

Turn the lens upside down



Step 5:

Turn the EZ Clean™ wipe to the other side



Step 6:

Using an "S" motion, wipe from top to bottom



Step 7:

Properly dispose the wipe and package

TALAS

Paardenkerkhofstraat 56 B-2800 Mechelen
Tel. +32(0)15.61.60.07 Fax. +32(0)15.61.75.27
Email. talas@talas.be

USING **EZ-Clean™** WIPES

Deeper Cleaning With **EZ Clean™ Plus** Wipes



Step 8:

Take out the folded EZ Clean™ Plus wipe



Step 9:

Using an "S" motion, wipe from top to bottom



Step 10:

Turn the lens upside down



Step 11:

Turn the EZ Clean™ Plus wipe to the other side



Step 12:

Using an "S" motion, wipe from top to bottom



Step 13

Properly dispose the wipe and package



Step 14:

Repeat steps 1-7 with a new EZclean™ wipe,
in order to remove residues

TALAS

Paardenkerkhofstraat 56 B-2800 Mechelen
Tel. +32(0)15.61.60.07 Fax. +32(0)15.61.75.27
Email. talas@talas.be



To maximize effectiveness of cleaning with **EZclean™** wipes we recommend:



- Wearing finger cots or rubber gloves



- Using Ophir lens holder



- Clean working environment

CONTAINS:

24 Lens cleaning wipes.

HEALTH HAZARD INFORMATION

for health hazard information, please refer to MSDS.



Warning: Cleaning liquid is flammable;
keep package away from hot surfaces

TALAS

Paardenkerkhofstraat 56 B-2800 Mechelen
Tel. +32(0)15.61.60.07 Fax. +32(0)15.61.75.27
Email. talas@talas.be